



WHY CHOOSE PRIME PROTECT?

Prime Protect is not just a service contract; it's a commitment to your vehicle's well-being and your peace of mind. When you choose Prime Protect, you're choosing a partner that will stand by your side throughout your vehicle's life journey.

Our team of experts is dedicated to ensuring that your vehicle remains in top condition, and we're just a phone call away whenever you need assistance. With Prime Protect, you can embrace worry-free vehicle ownership and focus on the joy of the open road.

AVERAGE REPAIR COSTS*** **BASED ON TYPICAL EXPENSES FUEL INJECTORS** \$2.283 RADIATOR \$1,242 A/C COMPRESSOR \$1,502 **TURBOCHARGER** \$2,083 TRANSMISSION \$4,069 ALTERNATOR \$935 STARTER \$837 ENGINE **FUEL PUMP** \$5,112 \$1.311 **TIMING CHAIN** \$2,853 **Based on typical repair costs as determined by CARS.

WHAT DOES A VEHICLE SERVICE CONTRACT DO FOR ME?

A vehicle service contract provides vehicle buyers with a safeguarding plan that delivers peace of mind, enhanced security, and financial savings. It alleviates concerns associated with purchasing a vehicle by assuring that a significant portion of repair expenses will be taken care of. This coverage substantially reduces the impact of unexpected repair costs, ultimately making vehicle ownership and maintenance more budget-friendly.

HOW DOES A PROTECTION PLAN WORK?

This plan offers support in the event of a covered mechanical breakdown or failure with your vehicle. When such an issue occurs, the repair facility gets in touch with the provider's claims center to initiate the claim process. A claims representative collaborates with the service center to confirm coverage, assess the root cause and extent of the failure, and subsequently arranges for the necessary repairs to be performed on your vehicle.

WHAT EXACTLY IS COVERED?

Your plan provides coverage for both parts and labor during covered repairs. With a choice of four distinct levels, you can pick the plan that aligns most closely with your specific needs and preferences.

WHAT'S THE DIFFERENCE BETWEEN A VEHICLE PROTECTION PLAN & A MANUFACTURER'S WARRANTY?

Manufacturer warranties are bundled with products and are factored into the manufacturer's suggested retail price. Vehicle service contracts, on the other hand, are frequently sold separately from the product and may not be part of the initial purchase.

HOW MUCH DOES A PROTECTION PLAN COST?

The expenses differ depending on the type of vehicle and its mileage. Your Sales Associate will collaborate with you to identify the most suitable plan for the vehicle you're acquiring and thoroughly go over the associated costs with you.

SHOULD I WAIT AND BUY A PLAN LATER?

The ideal time to purchase your plan is when you buy the vehicle. The option you select might not be available later.

WHAT ABOUT FINANCING?

Frequently, the expense of the plan can be incorporated into your financing, simplifying your payment process.

IS A PLAN TRULY NECESSARY?

While protection plans are optional, it's important to consider that pre-owned vehicles come with mileage and some degree of wear and tear. As you continue to drive, the likelihood of a mechanical failure naturally increases. Considering that your vehicle is one of your most valuable assets, a protection plan can significantly reduce your out-of-pocket repair costs. To find the most suitable protection plan for the vehicle you're buying, have a conversation with your Sales Associate, who can guide you through the available options.

> Monroeville, PA 15146 Florida License No. 32409





Includes The Items Listed Below:

COVERAGE DETAILS ee your contract for exact terms, coverages and exclusions.

LEVEL 2

Includes Everything In Level 1 In Addition To The Items Listed Below:

FNGINF*

ENGINE
Turbo Charger (Factory Installed)
Waste Gate Controller
Intercooler
Turbo/Supercharger Coolant Lines
Cylinder Heads
Intake Manifold
Pistons
Piston Rings
Wrist Pins
Connecting Rods & Bearings
Crankshaft & Bearings
Camshaft & Bearings
Crankshaft Pulley
Harmonic Balancer
Dipstick Tube
Timing Chain
Timing Belt
Timing Guides
Timing Chain Tensioner
Timing Belt Tensioner
EGR Valve
Serpentine Belt Tensioner
Timing Gears
Valve Covers
Rocker Arms/Shafts & Bushings
Intake/Exhaust Valves & Valve Springs
Seats
Guides
Push Rods & Hydraulic Lifters
Oil Pump
Oil Sending Unit
Oil Pan

MANUAL TRANSMISSION[®]

Main Shaft	
Counter Shaft	
All Gears	
Chain	
Input Shaft	
Hub Assemblies	
Synchronizers	
Shift Rails	
Shift Fork	

Internal Transmission Bearings

AUTOMATIC TRANSMISSION^{*}

Torque Converter
Flywheel
Bands
Pump
Transmission Cooler
Mechatronics Unit
Conductor Plate
Pump Housing
Carrier Assembly
Planetary Gears
Chain
Drums
Reaction Shaft
Governor
Valve Body
Servo Assemblies

ELECTRIC & HYBRID ENGINE

DRIVE AXLE^{*}

Drive Motor

Pinion Bearings Vheel Bearings ide Carrier Bearings Ring & Pinion ide Gears pider Gears & Case Prive Shaft Universal Joints Constant Velocity Joints ix 4 Hubs iront Or Rear Drive Axle Housing	
ide Carrier Bearings Ring & Pinion ide Gears pider Gears & Case Prive Shaft Iniversal Joints Constant Velocity Joints Ex4 Hubs	Pinion Bearings
Ring & Pinion de Gears pider Gears & Case Drive Shaft Universal Joints Constant Velocity Joints	Vheel Bearings
ide Gears pider Gears & Case Drive Shaft Universal Joints Constant Velocity Joints	ide Carrier Bearings
pider Gears & Case Drive Shaft Iniversal Joints Constant Velocity Joints Ex4 Hubs	Ring & Pinion
Drive Shaft Jniversal Joints Constant Velocity Joints Ex4 Hubs	ide Gears
Iniversal Joints Constant Velocity Joints -x4 Hubs	pider Gears & Case
Constant Velocity Joints x4 Hubs	Drive Shaft
x4 Hubs	Iniversal Joints
	Constant Velocity Joints
ront Or Rear Drive Axle Housing	x4 Hubs
	ront Or Rear Drive Axle Housing

FLUIDS

All Fluids (Including But Not Limited To)	iited To)	
Engine Oil		
Engine Coolant		
Transmission Fluid		
Brake Fluid		
Power Steering Fluid		

SEALS AND GASKETS

Cylinder Head & Intake Manifold Gaskets Coverage For Leakage Failures Under 150,000 Miles

FUEL Fuel/Diesel Fuel Supply/Lift/Transfer Pump

Fuel Injectors/Fuel Injection Control Module Fuel Filler Neck

SUSPENSION

Struts Ball Joints/Control Arms/Control Arm Shafts **Bump Stop Cushions** Steering Knuckle/Spindle Stabilizer Shaft/Stabilizer Links Leaf/Air & Coil Springs

BRAKE COMPONENTS

Master & Wheel Cylinders/Calipers/Booster Combination Valve Brake Hard Lines **Backing Plates** Springs & Clips Self Adjusters Parking Brake Linkage & Cables ABS Hydraulic Components AB

AB

S1

Po Ge Pit Steeri High-Pressure Lines

ENGINE COOLING SYSTEM

Radiator/Heater Core/Recovery Tank Water Pump/Thermostat Fan Shroud Electric Cooling Fan Motor Fan Clutch

AIR CONDITIONING

Compressor/Clutch/Condenser Heated/Cooled Seats & Evaporator Accumulator Orifice Tube Expansion Valve/Pressure Cycling Switch High/Low Pressure Cutoff Switches & Hoses Dryer

ELECTRICAL COMPONENTS

Starter Motor/Alternator Front & Rear Window Wiper Motor Oxygen, Crank, & Cam Sensor Electronic Control Module (ECM) Distributor/Ignition Coils Navigation (Does Not Include Software Updates) Power Window Motors/Regulators/Switches Power Seat Motors Power Door Lock Actuators/Switches Sunroof, Power Antenna, Headlight Motor Power Trunk/Sliding Door Motor Convertible Top Motor Window Defrosters (Front & Rear) Windshield Washer Pump **Throttle Position Sensor** 4WD Encoder Motor

your vehicle.

Please see your contract for the full list of exclusions.

THE PRODUCT BEING OFFERED IS A SERVICE CONTRACT AND IS SEPARATE AND DISTINCT FROM ANY PRODUCT OR SERVICE WARRANTY WHICH MAY BE PROVIDED BY THE MANUFACTURER, IMPORTER, OR SELLER.

> We have the option to select used, rebuilt, or aftermarket components when authorizing repairs. *Includes Internal Lubricated Parts

as hydraulic Components
3S Wheel Speed Sensors
3S Control Module
TEERING COMPONENTS
ower Steering Pump/Motor
ear Box/Rack & Pinion/Tie Rod Ends
tman & Idler Arm
eering Box Rack & Pump Housing

Sealing Rings Fluid Reservoir Cooler

LEVEL 3

Mechanical & Electrical Parts

EXCLUSIONS

Seals & Gaskets (If Your Vehicle Is Over 150,000) Manual Transmission Clutch Assembly Friction Clutch Disc & Pressure Plate Throw Out Bearing/Slave Cylinder Manual & Hydraulic Linkages Exhaust Manifold/Batteries Brake Rotors & Drums/Catalytic Converter Exhaust & Tail Pipes/Mufflers/Resonators Tires, Valve Stems & Wheels/Rims Glass/Windows/Mirrors/Windshields Safety Restraint Systems/Light Bulbs/Fuses Spark & Glow Plugs/Spark Plug Wires Hoses (Except Steering & Air Conditioning) Brake Pads/Lining/Shoes **Retainers & Wiper Blades**



Includes All Original Factory-Equipped

WRAP

Includes Everything In Level 3 Except The Engine, Electric & Hybrid Engine, Automatic Transmission, Manual Transmission, & Drive Axle Components

ADDITIONAL BENEFITS INCLUDED ON ALL LEVELS

Rental Benefits Towing Reimbursement Labor & Diagnostic Charges

24 Hour Roadside Assistance

With Level 3 coverage, you'll enjoy the highest standard of worry-free protection for

MORE INFO? CALL OR SCAN 866.446.4537

